

set_tracking.php

Sets the locating interval, at ignition on for a vehicle. Switches hardware specific the travel interval, time interval or course change.

Description

POST

`set_tracking.php?company=COMPANY_RTIKEY&vehicle=VEHICLE_RTIKEY&,mode=intelligentlocating&value=active`

Parameter

Parameter	Description	Type	Note	Mandatory
company	RTI company key	string		yes
vehicle	RTI vehicle key	string		yes
mode	which type of locating interval should be set	string	- coursechange - distanceinterval - minuteinterval - intelligentlocating	yes
value	Value of the selected interval	int/string	see "Possible values"	yes

Possible values

Parameter	Description	Type	Possible values
coursechange	Locate at ignition on at course change	int	0 = off 1 = on
distanceinterval	Locate with ignition on for all X km	int	0 = Kilometer tracking deactivated 1 = Locate every km 2 = Locate every 2 km 5 = Locate every 5 km 10 = Locate every 10 km
minuteinterval	Locate with ignition on for all X min	int	0 = Time interval disabled 1 = Locate every 1 minutes 2 = Locate every 2 minutes 5 = Locate every 5 minutes 10 = Locate every 10 minutes 15 = Locate every 15 minutes 30 = Locate every 30 minutes
intelligentlocating	when all 3 locating intervals are activated	string	- inactive - active

Return

By default, a **CSV string** is returned, which contains **OK** for each vehicle on success. If an error occurs, an **"ERROR:Description"** is returned.

Example calls

sets the locating interval to 5 km

```
https://map.yellowfox.de/rti/set_tracking.php?company=COMPANY_RTIKEY&vehicle=VEHICLE_RTIKEY&mode=distanceinterval&value=5
https://map.yellowfox.de/rti/set_tracking.php?company=COMPANY_RTIKEY&vehicle={"type":"car_ident","groupKey":"GROUP_RTIKEY","ident":"VEHICLE_IDENT"}&mode=distanceinterval&value=5
```

sets the locating interval to 2 minutes

```
https://map.yellowfox.de/rti/set_tracking.php?company=COMPANY_RTIKEY&vehicle=VEHICLE_RTIKEY&mode=minuteinterval&value=2  
https://map.yellowfox.de/rti/set_tracking.php?company=COMPANY_RTIKEY&vehicle={"type":"car_ident","groupKey":"GROUP_RTIKEY","ident":"VEHICLE_IDENT"}&mode=minuteinterval&value=2
```

activates the change of course

```
https://map.yellowfox.de/rti/set_tracking.php?company=COMPANY_RTIKEY&vehicle=VEHICLE_RTIKEY&mode=coursechange&value=1  
https://map.yellowfox.de/rti/set_tracking.php?company=COMPANY_RTIKEY&vehicle={"type":"car_ident","groupKey":"GROUP_RTIKEY","ident":"VEHICLE_IDENT"}&mode=coursechange&value=1
```

activates the intelligent tracking

```
https://map.yellowfox.de/rti/set_tracking.php?company=COMPANY_RTIKEY&vehicle=VEHICLE_RTIKEY&mode=intelligentlocating&value=active  
https://map.yellowfox.de/rti/set_tracking.php?company=COMPANY_RTIKEY&vehicle={"type":"car_ident","groupKey":"GROUP_RTIKEY","ident":"VEHICLE_IDENT"}&mode=intelligentlocating&value=active
```